





1. Using a PC laptop or computer, simply plug in the USB stick and download the TAP software.



Click 'YES'

2. Once the software is downloaded, open the ESL Vision App by clicking the icon. A screen will appear blank.




3. Plug the TAP Wand into the computers USB port.




4. Hold the wand over the TAP indicator on the fixture and click READ.



5. The default wattage and kelvin will appear.



6. To change the settings, select the desired Wattage and Kelvin.



7. Click WRITE. Your fixture is ready to go!

