WALL PACK SERIES

Gen 5 — Installation Guide

Page 1 of 1

WARNING

- 1. To avoid electric shock, disconnect power at source prior to installation.
- 2. The installation should be performed by qualified electricians or lighting technicians.
- 3. Before conducting any installation, maintenance, or removal, disable all power.
- 4. Do not touch the fixture while it is in service.
- 5. If there is any problem with the fixture, turn off power and DO NOT attempt repair unless you are a qualified technician or the customer service member.

Junction Box Mounting

Loosen the two (2) screws on the side of the housing to open fixture.


5 Set the kelvin & wattage to the desired levels.

Prepare the back plate for mounting by drilling or knocking out the appropriate holes. Refer to the backplate diagram section.


6 Close the door & tighten the two (2) screws on the side of the housing

3 Line up the back plate in the desired location and mount securely using mounting bolts. Caulk the bolt heads.


4 Complete the wiring to the supply wires & ground (refer to wiring diagrams).



Electrical Wiring Diagram




Electrical Wiring Diagram (With EM Backup)



Backplate Diagram

- A 5/16" dia. Knockouts
- B 9/16" dia. Knockouts
- C Knockouts for #10 screw
- D 1/2" NPS tapped holes.



Copyright © 2021 ESL Vision, LLC. All rights reserved. Rev: 11/18/21

